

Quick Reference Cleaning Sheet

While Floraline fixtures supply fresh water to your flowers at a predetermined time, it is still recommended that a regular cleaning program be implemented to ensure product longevity.

The recommended cleaning procedures:

- Clean the case exterior and vases, weekly (See **W1**).
- Drain and clean tubes, monthly (See **M1-M5**).
- Remove **ONLY** tube #1 and clean case bottom and drains, yearly (See **Y1-Y5**).

Weekly Vase Cleaning (W1):

W1- Using a damp sponge or cloth, disinfect each vase by wiping it out with cleaner.

Monthly Tube Cleaning (M1-M5):

M1- Insert and turn key *clockwise* to turn fixture **OFF**. The key cannot be removed when in the **OFF** position. **M2-** Light will turn from **GREEN (Normal)** to **RED (Cleaning Mode)**. **M3-** Press and release button to flush each row. Press button once for row one, twice for row two, etc ... Insert a large sponge or cloth through the access door (**M4**) and clean inside the tube (**M5**). Turn key counterclockwise to restore power and remove key. Light will turn **GREEN** to show case is back to normal operation.

Yearly Removal of Tube #1:

Remove the fill fitting (**Y1**) and the flush fitting (**Y2**) **BY HAND**. Find the float connection (**Y3**) and disconnect (**Y4**). Now you can lift the entire tube out to the fixture (**Y5**) and clean the case bottom and drains. When re-connecting the fill and flush fittings **HAND TIGHTEN ONLY - USE NO TOOLS**.

